

MICRON Firmware update

Version 1.0

1. Copy new firmware files to USB stick (micronUp.frm and/or micronFP.frm).
2. Power OFF Micron.
3. Press and hold button 1+ 3 on Micron.
4. Power ON while holding buttons.
5. Release buttons.
6. Micron will signal boot-mode with the 2 red LEDs ON.
7. After some seconds Micron will load new firmware signaled with all LEDs ON.
8. Micron will turn OFF all LEDs when firmware upload is done.
9. Recycle power to reboot Micron.

